

Recording Menu (Video)

You can adjust various settings, such as brightness and white balance, to suit the subject or purpose. You can also change settings such as picture quality and gain.

Setting	Details
MANUAL SETTING	Recording settings can be adjusted manually. <ul style="list-style-type: none"> • They are displayed only when recording in the manual mode.
FACE PRIORITY AE/AF	Detects faces and adjusts the brightness and focus automatically.
LIGHT	Turns on/off the light.
REGISTER EVENT	Categorizes your videos according to events (such as "Travel", "Athletic Meet") by registering the file before recording.
VIDEO QUALITY	Sets the video quality.
ZOOM	Sets the maximum zoom ratio.
GAIN UP	Makes the subject appear bright automatically when recording in dark places.
HIGH SPEED RECORDING	Performs recording at an increased speed, or in slow-motion to emphasize the movements.
TIME-LAPSE RECORDING	Enables the changes of a scene that occur slowly over a long period to be shown within a short time by taking frames of it at a certain interval.
AUTO REC	Enables the unit to start or stop recording automatically by sensing the changes in brightness within the red frame displayed on the LCD monitor.
SEAMLESS RECORDING	Automatically switches to a different media and continues recording when the remaining space on the current recording media runs out. For example, when the remaining space on the SD card runs out during recording, the recording continues on the built-in memory without stopping.
SHUTTER MODE	Continuous shooting settings can be adjusted.
x.v.Color	Records with "x.v.Color".
WIND CUT	Reduces the noise caused by wind.