MONITOR BRIGHTNESS

Sets the brightness of the LCD monitor.

1 Touch 🅜 to display the menu.

2 Select "DISPLAY SETTINGS" and touch 🆗.

3 Select "MONITOR BRIGHTNESS" and touch 🆗.

4 Adjust the brightness of the monitor.

- Slide upward to increase the brightness.
- Slide downward to decrease the brightness.
- After setting, touch 🆗.